




WASHER/DRYER CONTROL PANEL PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)


WASHER/DRYER
LAUNDRY SYSTEM



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3405970	Literature Parts Installation Instructions	7	3390646	Screw, Dryer Timer Mounting (8-18 x 5/16)	22	3390646	Screw, Dryer Timer Mounting (8-18 x 5/16)
	LIT3401098	Use & Care Guide	692993	692993	White	23	3977194	Panel, Control White
	LIT3954157	Energy Guide	3978584	3978584	Biscuit	24	3977195	Biscuit
	LIT3952874	Wiring Diagram	348689	348689	Screw, End Cap Mounting (4) (8-18 x 3/4)	25	24	Knob, Timer (Dryer)
2	3406288	Harness, Console Wiring (Automatic) (Includes Illus. 2A, 2B & 2C)	694091	694091	Screw, Mounting (2) (8-18 x 3/8)	3406143	3406143	White
2A	3350130	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)	3362987	3362987	Switch, Water Level	3978872	3978872	Biscuit
2B	696073	Receptacle, Connector (Connects With Lower Automatic Harness)	8054142	8054142	Switch, Water Temperature	25	25	Knob, Push-To-Start
2C	3948614	Disconnect Block (Connects With Automatic Timer)	693711	693711	Sleeve, Console Lock Screw (2)	3406133	3406133	White
5	3952499	Timer, Control (60 Hz.) (Automatic Washer)	693151	693151	Spring, Console Lock (2)	3978871	3978871	Biscuit
6	8528154	Bracket, Control	3400860	3400860	Screw, Console Lock (2)	27	27	Knob, Control (2)
			3406720	3406720	Timer, Control (60 Hz.) (Dryer) (Timer Motor Not Serviceable)	3950759	3950759	White
			3977456	3977456	Switch, Push-To-Start	3978873	3978873	Biscuit
			18	18	Push-To-Start	28	28	Dial, Timer (Washer)
			19	693152	Not Serviceable)	3950762	3950762	White
			21	694037	Switch, Push-To-Start	3978870	3978870	Biscuit
					Bumper, Console (5)	29	29	Knob, Timer (Washer)
					Clip, Console	31	3951026	White
						32	3978869	Biscuit
							692983	Lock, Console (2)
							694419	Buzzer

DRYER FRONT PANEL AND DOOR PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3406108	Door Switch	10	685203	Clip, Felt Pad (2)	14	3389441	Catch, Door Handle, Door
2	697773	Screw, 6-20 x 7/8	11	696144	Strike, Panel	15	686711	White
4	692619	Panel, Front	12	3390663	Screw, Door Switch Mounting (2)	16	3978592	Biscuit
	3978587	White	13	343641	Screw, 10-16 x 1/2 (2) (Front Panel To Side Panel)	19	692846	Support Protector
5	3390734	Seal, Door				19	694091	Screw, Door Mount To Hinge & Panel (10)
6	695656	Door, Rear				20	348023	Hinge & Pin, Door (2)
7	348205	Door, Front						
	3978598	White						
9	3978598	Biscuit						
	8066123	Bearing & Seal						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS


For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor Mounting (2)	18	686770	Support, Protector	29		Panel, Side (R.H.)
2	8066068	Motor, Main Drive (60 Hz.)	20	8066064	Belt, Drive	3402287	3402287	White
5	696541	Bracket, Motor	21	8066051	Pulley, Motor (60 Hz.)	3978590	3978590	Biscuit
6	3390405	Panel, Rear	22	3394332	Idler & Slide Assembly	30	693145	Latch, Lid
7	343641	Screw, 10-16 x 1/2	23	692771	Nut, Idler Bracket To Base	31		Closure, Control Area
8	3394228	Cover, Terminal Block	24	3399632	Base, Dryer	692781	692781	White
9	90296	Clip	25	692400	Nut, Push-In	3978599	3978599	Biscuit
10		Panel, Side (L.H.)	26	692926	Cove, Transition Panel (Black)	32	354975	Screw & Washer (3) (Lid Latch Mounting)
	3402293	White	27		Panel, Transition	33	693304	Screw & Washer (2) (Transition Panel To Closure)
	3978589	Biscuit		692933	White	34	697776	Screw, Ground (10-32 x 5/8)
14	3399602	Elbow, Upper		3978591	Biscuit	35	3390631	Screw, 10-16 x 3/8
15	3394083	Clip, Front Panel (2)	28	692641	Top, Dryer	36	661606	Capacitor, Motor Start (Automatic Washer)
16	98234	Clip, Ground				37	357030	Clamp, Capacitor
17	3399603	Elbow, Lower						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

**For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)**



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, 10-16 x 1/2	19	3404154	Thermostat, Heater Box (200°F)	36A	717252	Receptacle, Terminal (2-Way) (Connects With Door Switch Harness)
2	3395396	Clip, Air Duct To Bulkhead	20	3406652	Resistor Assembly	36B	3395683	Receptacle, Multi-Terminal (Connects With Motor)(Dryer)
3	696547	Air Duct & Bracket	21	3399507	Shaft, Drum Roller (R.H.)	37	693141	Clip, Wiring Harness (3)
4	90767	Screw, 8-18 x 3/8	22	695943	Drum, Dryer	39	279457	Wire Kit (For Heater Element Wiring Harness Repair)
5	3398128	Thermostat, Internal Bias	23	3394508	Ring, Bearing	40	8066086	Drum,Hole Plug
6	3393008	Screw, Terminal Block To Bracket (2)	24	685207	Baffle, Drum (3)	41	279393	Screw Kit (For Terminal Block)
7	3397659	Block, Terminal	25	97787	Screw, Baffle Mounting (6) (11-16 x 3/4)	42	279318	Terminal, Tinned & Brass (3) (Includes Illus. 41)
8	3388703	Washer	26	345648	Seal, Drum Rear	43	697776	Screw, Ground (2) (10-32 x 5/8)
9	489463	Screw, 8-18 x 5/8	27	695931	Bulkhead	48	359702	Cap, Screw
10	3398161	Clip, Heater Box To Bulkhead	28	348399	Lint Screen	49	255563	Clip, Strain Relief
11	3401380	Heater Box	29	685273	Cover, Lint Screen Outlet			
12	3403586	Element, Heater	30	690997	Tri-Ring (4)			
13	339956	Seal, Air Duct To Bulkhead	31	3399506	Shaft, Drum Roller (L.H.)			
14	696426	Wheel, Blower	32	3397588	Roller, Support (2)			
15	3399849	Fuse, Thermal	33	348197	Washer, Support (4)			
16	8066094	Seal, Fan Scroll	34	3359452	Nut, 3/8-16 (2)			
17	696418	Fan Scroll	35	3390631	Screw, 10-16 x 3/8			
18	3390647	Screw, 8-18 x 1/2	36	3406941	Harness, Main Dryer Wiring (Includes Nos.36A, 36B)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER SUPPORT AND WASHER PARTS

For Models: LTE5243DQ3, LTE5243DT3


(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	694304	Cover, Channel
2	692647	Support, Dryer (L.H.)
3	343641	Screw, 10-16 x 1/2
4	3400000	Screw, 10-24 x 3/8 (8)
		(Washer Cabinet To Dryer Supports)
5	692646	Support, Dryer (R.H.)
6	3954108	Harness, Lower (Automatic) (Includes Illus. 6A, 6B & 6C)
6A	696074	Plug, Terminal (12-Way) (Connects With Automatic Console Harness)
6B	62889	Plug, Terminal (3-Way) (Connects With Automatic Lid Switch Harness)
6C	62505	Block, Disconnect (Connects With Automatic Washer Motor)
7	3347812	Clip, Wiring Harness (4)
8	3405028	Clip
9	685463	Kit, Grounding
10	685449	Wire, Ground
11	90016	Clip, Pressure Switch Hose (2)
12	693141	Clip, Harness And Hose
13	22965	Strap, Ground
14	3400902	Nut, Hex
15	3400036	Screw, 10-24 x 1
16	3351614	Screw, 10-24 x 3/8
17	8066080	Hose, Pressure Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER TOP AND LID PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
3		Lid	12		Top	16	358684	Strike, Lid
	3398843	White		384693	White			Switch
	3398847	Biscuit		3978593	Biscuit	17	384459	Hinge, Lid (R.H.)
4	384475	Bumper, Lid (2)	13	19119	Bumper, Lid	18	3400030	Screw, Ground
5	384458	Hinge, Lid (L.H.)			Hinge (2)			(10-24 x 1/2)
7	3351355	Screw, Lid	14	21258	Bearing, Lid	20	3400901	Nut, Ground
		Hinge Mounting (4)			Hinge (2)			Screw (10-24)
8	343641	Screw, 10-16 x 1/2	15	3356311	Screw & Washer,	22	3355806	Switch, Lid
9	692985	Clip, Spring (2)			Lid Switch		90016	Clip, Harness
		(Top To Cabinet)			Shield (2)			Routing

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	356746	Clip, Condenser
2	343641	Screw, 10-16 x 1/2
3	9740848	Screw, Mixing Valve Mounting (8-18 x 1/2)
4	370451	Clamp, Hose
5	3952163	Valve, Water Mixing
7	692699	Hose, Water Inlet (Siphon Break To Mixing Valve)
8	696013	Cabinet White
	3978594	Biscuit
10	696710	Hose, Drain
11	692400	Nut, Push-In (2)
12	660975	Plug, Top To Cabinet
13	356739	Connector, Hose
15	356471	Cap, Siphon Break
16	356363	Siphon Break
17	272861	Clamp, Hose
18	696394	Hose, Water Inlet (Siphon Break To Tub Ring)
21	660628	Clamp, Hose
22	3394083	Clip, Front Panel (2)
23	358652	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27	692628	Panel, Front White
	3978596	Biscuit
28	367594	Foot, Front (2)
29	358594	Foot, Rear (2)
30	3400000	Screw, 10-24 x 3/8 (Washer Cabinet To Dryer Supports)
32	3390046	Protector, Edge



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)

Illus.	Part No.	DESCRIPTION
1	387948	Brake And Drive Tube (Complete) (Refer To Page 16 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951312	Clutch (Complete)
6	3951308	Band And Lining (Includes Illus. 7 & 8)
7	3946846	Spring, Clutch
8	62646	Cap, Clutch Spring (2)
9	3360630	Gearcase (Complete) (Refer To Page 15 For Further Breakdown)


Illus.	Part No.	DESCRIPTION
10	3357334	Screw, (3) (Gearcase To Tub Support)
11	62611	Plate, Motor Mount To Gearcase
13	3364003	Coupling, Motor & Isolating
14	661600	Motor, Main Drive
16	3946532	Plate, Motor
18	3363394	Pump, Complete
19	62700	Retainer, Pump
20	62850	Switch, Main Drive Motor
21	62691	Grommet, Motor (4)
22	3349637	Retainer, Motor (2)
23	3350013	Foam
24	3387485	Screw, 10-16 x 5/8
25	3355454	Clip (Anti-Rattle)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)




Illus.	Part No.	DESCRIPTION
1	285203	Centerpost Bearing Kit (Incls. Illus. 10, 11, & 12)
3	64137	Shield, Tub
4	388492	Spring, Counterweight
5	3406201	Suspension Assembly (3)
6	63755	Base
10	356934	Seal, Centerpost
11	3347047	Bearing, Centerpost (2)
12	357409	Seal, Centerpost
13	63134	Ring, Sound Deadening
14	3400076	Screw, 10-32 x 5/8
15	63636	Bracket, Counterweight Spring
17	63637	Shield, Tub
18	3351021	Nut, 1/2 - 13 (3)
19	63740	Tub Support and Drum
21	64247	Screw, 10-16 x 1/2
22	90767	Screw, 8-18 x 3/8
23	386011	Screw & Washer (Base To Cabinet)
24	696044	Block, Restraint

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND BASKET PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
3	63840	Filter, Agitator
4	3349098	Agitator
5	64175	Tub Ring & Gasket (Includes Illus. 7, 14 & 15)
6	21366	Nut, Spanner
7	3359587	Gasket, Tub Ring
8	3351985	Basket
9	8066081	Tub
10	389140	Block, Basket Drive
11	3949550	Washer
12	371502	Clamp, Hose
13	386929	Hose, Tub To Pump
14	352155	Clip, Retaining
15	356398	Tube, Drain Off
16	357640	Screw & Washer (Tub Mounting)
17	383727	Gasket, Centerpost

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER WATER SYSTEM PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)




WS900B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)




Illus.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

GC-215-C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: LTE5243DQ3, LTE5243DT3
 (Designer White) (Biscuit)




BD-313B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PRODUCT ACCESSORY PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)




Illus.	Part No.	DESCRIPTION
--------	----------	-------------

- | | | |
|---|---------|---------------------------------------|
| 1 | 279823 | Side Exhaust Extension Kit (Complete) |
| 2 | 488729 | Screw, 8-18 x 1/2 |
| 3 | 3395536 | Clip |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: LTE5243DQ3, LTE5243DT3
(Designer White) (Biscuit)



OPTIONAL PARTS (NOT INCLUDED)

Illus. Part No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray
350930 White
4392901 Biscuit

Illus. Part No. No. DESCRIPTION

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)

OIL

350572 Oil, Gearcase (16 Oz.)

Illus. Part No. No. DESCRIPTION

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST